



Breakout Box inputs and outputs



- | | |
|---|--|
| 1 | Power input 10V-20V
When using batteries without deep discharge protection (12V), the Breakout Box will automatically shut down at 10V and restart at 11V |
| 2 | Output for the Sony Professional Finder DXF 801 with max. 1A (protected by a poly switch) |
| 3 | 7,2V outputs with a total max. of 2A (protected by IC overload function) |
| 4 | Input for S-Video signal coming from camcorder |
| 5 | 4-pin video output, which can take a max. of 4A and suitable for all Arri standard accessories (protected by an IC overload function) |
| 6 | Two 12V power outputs with a total max. power of 5A for accessories (protected by IC overload function) |

Breakout Box Ein- und Ausgänge



- | | |
|---|--|
| 1 | Stromeingang 10V-20V
Akkus ohne Tiefentladeschutz werden automatisch bei 10V abgeschaltet. Der Schwellwert für den Start der Breakout-Box ist 11V |
| 2 | Ausgang für den Profisucher von Sony DXF 801
(abgesichert mit max. 1A Poly-Switch Sicherung) |
| 3 | zwei 7,2V Ausgänge (Summenstrom abgesichert mit jeweils 2 A IC - Überlastungsschutz) |
| 4 | S-Video Eingang |
| 5 | Videoausgang kombiniert mit 12 V Versorgungsspannung, ARRI Standard
(abgesichert mit 4A IC Überlastungsschutz) |
| 6 | Zwei 12 V Ausgänge
(Summenstrom abgesichert mit 5A IC - Überlastungsschutz) |